

We recommend conducting routine maintenance (about once a year) by carrying out the following tasks:

- Clean upper track (remove dust and deposits from the track's surface)
- Check if all fixing screws within the upper track are assembled and fastened
- Check the height adjustment and setting of each single panel
- Check if counter nuts and safety screws are adequately fastened
- Check if all rollers can be moved easily
- Check position of all cover rails and covers
- Check position of buffers / end buffers
- Check if floor sockets, locking plates and lower tracks are adequately fastened and clean
- Ensure that lock and profile cylinder can be moved easily
- Check glass panels for conchoidal fractures (have them replaced if necessary)
- Remove dirt from fittings with warm water or common cleaners
- For cleaning the glass panels only use common glass cleaner